

Fejlkoder for Saab 9-3 MY2006

ACC
B1927 02 - Heating in left-hand seat not working.
B0313 63
B0165 02
B0166 05
B0175 02
B0176 05
B0180 02
B0181 05
B0183 08 - Deteriorated climate comfort.
B0184 06 - Deteriorated climate comfort.
B0185 02 - Deteriorated climate comfort.
B0186 01 - Deteriorated climate comfort.
B0193 08 - Possible ventilation fan malfunction. Possible AC malfunction.
B0194 38 - Faulty function of ventilation fan. No A/C function.
B0195 02 - The ventilation fan is not working. No A/C function.
B0197 04 - The ventilation fan is not working. No A/C function.
B0225 06 - Possible poor air quality in cabin. Possible problem with mist on car windows. Possible inferior AC performance in high outdoor temperatures.
B0226 01 - Possible poor air quality in cabin. Possible problem with mist on car windows. Possible inferior AC performance in high outdoor temperatures.
B0240 06 - Incorrect air distribution.
B0241 01 - Incorrect air distribution.
B0250 06 - Incorrect air distribution.
B0251 01 - Incorrect air distribution.
B0255 06 - Incorrect air distribution.

B0256 01 - Incorrect air distribution.
B0260 06
B0261 01
B0410 06 - Defective temperature control.
B0411 01 - Defective temperature control.
B0420 06 - Defective temperature control.
B0421 01 - Defective temperature control.
B0511 02
B0512 05
B0516 02
B0517 05
B0521 02
B0522 05
B1928 05 - Heating in left-hand seat not working.
B2172 02 - Heating in right-hand seat not working.
B2173 05 - Heating in right-hand seat not working.
B2428 01 - Seat heating inoperative.
B2433 01 - No seat heating.
B2434 04 - No seat heating.
B1000 36 - Possible deterioration in climate comfort.
B1000 37
B1001 41
B1013 31 - Possible deterioration in climate comfort.
B2429 06 - No seat heating. Or Seat heater will not turn off.

ACM
B0012 0E - Airbag warning lamp is lit.
B0013 04 - Airbag warning lamp is lit.
B0014 01 - Airbag warning lamp is lit.
B0014 02 - Airbag warning lamp is lit.
B0016 0E - Airbag warning lamp is lit
B0017 04 - Airbag warning lamp is lit.
B0018 01 - Airbag warning lamp is lit.
B0018 02 - Airbag warning lamp is lit.
B0022 0E - Airbag warning lamp is lit
B0024 01 - Airbag warning lamp is lit.
B0024 02 - Airbag warning lamp is lit.

B0026 04 - Airbag warning lamp is lit.
B0028 0E - Airbag warning lamp is lit
B0029 04 - Airbag warning lamp is lit
B0030 01 - Airbag warning lamp is lit
B0030 02 - Airbag warning lamp is lit
B0040 0E - Airbag warning lamp is lit
B0041 04 - Airbag warning lamp is lit
B0042 0E - Airbag warning lamp is lit.
B0043 01 - Airbag warning lamp is lit.
B0043 02 - Airbag warning lamp is lit.
B0044 04 - Airbag warning lamp is lit.
B0045 01 - Airbag warning lamp is lit
B0045 02 - Airbag warning lamp is lit
B0053 00 - Airbag warning lamp is lit
B0057 0E - Airbag warning lamp is lit
B0058 00 - Airbag warning lamp is lit
B0059 01 - Airbag warning lamp is lit
B0059 02 - Airbag warning lamp is lit
B0061 0E - Airbag warning lamp is lit
B0062 04 - Airbag warning lamp is lit
B0064 0E - Airbag warning lamp is lit
B0065 04 - Airbag warning lamp is lit
B0066 01 - Airbag warning lamp is lit
B0066 02 - Airbag warning lamp is lit
B0068 01 - Airbag warning lamp is lit
B0068 02 - Airbag warning lamp is lit
B0069 0E - Airbag warning lamp is lit
B0070 04 - Airbag warning lamp is lit
B0071 01 - Airbag warning lamp is lit
B0071 02 - Airbag warning lamp is lit
B0077 00 - Airbag warning lamp is lit
B0078 00 - Airbag warning lamp is lit
B0080 00 - Airbag warning lamp is lit
B0079 00 - Airbag warning lamp is lit
B0081 00 - Airbag warning lamp is lit
B0082 00 - Airbag warning lamp is lit
B0083 01 - Airbag warning lamp is lit

B0083 08 - Airbag warning lamp is lit
B0084 01 - Airbag warning lamp is lit
B0084 06 - Airbag warning lamp is lit
B0084 08 - Airbag warning lamp is lit
B0096 01 - Airbag warning lamp is lit
B0096 08 - Airbag warning lamp is lit
B0097 01 - Airbag warning lamp is lit
B0097 08 - Airbag warning lamp is lit
B0100 00 - Airbag warning lamp is lit
B0101 00 - Airbag warning lamp is lit
B0102 00 - Airbag warning lamp is lit
B0103 00 - Airbag warning lamp is lit
B0104 00 - Airbag warning lamp is lit
B0105 00 - Airbag warning lamp is lit
B0109 0E - Airbag warning lamp is lit
B0110 04 - Airbag warning lamp is lit
B0118 0E - Airbag warning lamp is lit
B0119 04 - Airbag warning lamp is lit
B0120 01 - Airbag warning lamp is lit
B0120 02 - Airbag warning lamp is lit
B0121 0E - Airbag warning lamp is lit
B0122 04 - Airbag warning lamp is lit
B0123 01 - Airbag warning lamp is lit
B0123 02 - Airbag warning lamp is lit
B1000 00 - Airbag warning lamp is lit
B1001 00 - Airbag warning lamp is lit
B1019 00 - Airbag warning lamp is lit
B3855 00 - Airbag warning lamp is lit
B3856 00 - Airbag warning lamp is lit
B3857 00 - Airbag warning lamp is lit
B3858 00 - Airbag warning lamp is lit
B3859 00 - Airbag warning lamp is lit
B3860 00 - Airbag warning lamp is lit
B0051 00 - Airbag warning lamp is lit
B0014 00 - Airbag warning lamp is lit.
B0018 00 - Airbag warning lamp is lit.
B0024 00 - Airbag warning lamp is lit.

B0058 04 - Airbag warning lamp is lit
B0083 06 - Airbag warning lamp is lit
B0096 06 - Airbag warning lamp is lit
B0097 06 - Airbag warning lamp is lit
B1001 41 - Airbag warning lamp is lit
B0030 00 - Airbag warning lamp is lit
B0043 00 - Airbag warning lamp is lit.
B0066 00 - Airbag warning lamp is lit
B0068 00 - Airbag warning lamp is lit
B0071 00 - Airbag warning lamp is lit
B0123 00 - Airbag warning lamp is lit
B0120 00 - Airbag warning lamp is lit
B0045 00 - Airbag warning lamp is lit

AHL
B1000 00 - Message appears in display. Headlamp beam adjustment not working.
B1001 08 - Message appears in display. Headlamp beam adjustment not working.
B1001 42 - Message appears in display. Headlamp beam adjustment not working.
B1001 46 - Message appears in display. Headlamp beam adjustment not working.
B1325 03 - Message appears in display. Headlamp beam adjustment not working.
B3410 02 - Message appears in display. Headlamp beam adjustment not working.
B3410 05 - Message appears in display. Headlamp beam adjustment not working.
B3415 01 - Message appears in display. Headlamp beam adjustment not working.
B3415 02 - Message appears in display. Headlamp beam adjustment not working.
B3420 02 - Message appears in display. Headlamp beam adjustment not working.
B3420 05 - Message appears in display.
B3435 02 - Message appears in display. Headlamp beam adjustment not working.
B3435 05 - Message appears in display. Headlamp beam adjustment not working.
B3435 54 - Message appears in display. Headlamp beam adjustment not working.
B3440 02 - Message appears in display. Headlamp beam adjustment not working.
B3440 05 - Message appears in display. Headlamp beam adjustment not working.
B3440 54 - Message appears in display. Headlamp beam adjustment not working.
B3410 08 - Message appears in display. Headlamp beam adjustment not working.
B3420 08 - Message appears in display. Headlamp beam adjustment not working.

AHM/PHM
B0438 01 - Poor cabin heating Heater does not start.

B0438 02 - Poor cabin heating Heater does not start.
B0442 00 - Poor cabin heating Heater does not start.
B0443 01 - Poor cabin heating Heater does not start.
B0443 02 - Poor cabin heating Heater does not start.
B0447 00 - Poor cabin heating Heater does not start.
B0448 01 - Poor cabin heating Heater does not start.
B0448 02 - Poor cabin heating Heater does not start.
B0449 00 - Poor cabin heating Heater does not start.
B0452 00 - Poor cabin heating Heater does not start.
B0453 00 - Poor cabin heating Heater does not start.
B0457 00 - Poor cabin heating Heater does not start.
B0458 00 - Poor cabin heating Heater does not start.
B0462 00 - Poor cabin heating Heater does not start.
B0463 00 - Poor cabin heating Heater does not start.
B0467 00 - Poor cabin heating Heater does not start.
B0468 01 - Poor cabin heating Heater does not start.
B0468 02 - Poor cabin heating Heater does not start.
B0472 00 - Poor cabin heating
B0478 00 - Poor cabin heating
B0480 00 - Poor cabin heating
B0481 00 - Poor cabin heating
B0482 00 - Poor cabin heating
B0483 00 - Poor cabin heating Heater does not start.
B0484 00 - Poor cabin heating Heater does not start.
B0485 00 - Poor cabin heating Heater does not start.
B0486 00 - Poor cabin heating Heater does not start.
B0488 00 - Poor cabin heating Heater does not start.
B1000 00 - Poor cabin heating Heater does not start.
B1000 0F - Poor cabin heating Heater does not start.
B1000 34 - Poor cabin heating Heater does not start.
B1000 35 - Poor cabin heating Heater does not start.
B1000 36 - Poor cabin heating Heater does not start.
B1000 37 - Poor cabin heating Heater does not start.
B1000 38 - Poor cabin heating Heater does not start.
B1001 00 - Poor cabin heating Heater does not start.
B1004 00 - Poor cabin heating Heater does not start.
B1424 00 - Poor cabin heating Heater does not start.

B1425 00 - Poor cabin heating Heater does not start.
U2103 00 - Poor cabin heating Heater does not start.

AMP1
B1000 32 - Amplifier not functioning.
B1000 33 - Amplifier not functioning.
B1000 34 - Amplifier not functioning.
B1000 35 - Amplifier not functioning.
B1000 36 - Amplifier produces poor sound.
B1000 57
B1001 41 - Control module not configured.
B1016 00 - Control module not configured.
B3057 48 - Control module not configured.
B3899 48 - Control module not configured.
B3900 48 - Message appears in display. Car does not start.
B3902 70 - Message appears in display. Audio system not functioning.
U2155 1F - Intermittent amplifier function.

AMP2
B1000 32 - Amplifier not functioning.
B1000 33 - Amplifier not functioning.
B1000 34 - Amplifier not functioning.
B1000 35 - Amplifier not functioning.
B1000 36 - Amplifier produces poor sound.
B1000 57
B1001 41 - Control module not configured.
B1016 00 - Control module not configured.
B3057 48 - Control module not configured.
B3899 48 - Control module not configured.
B3900 48 - Message appears in display. Car does not start.
B3902 70 - Message appears in display. Audio system not functioning.
U2155 1F - Intermittent amplifier function.

BCM
B3011 02 - Message appears in display.
B2530 05 - Front fog lights not working.
B3011 05 - Message appears in display.

B3095 0F - Message appears in display.
B0158 02 - Fault in outdoor temperature function in SID.
B0158 05 - Fault in outdoor temperature function in SID.
B0969 02 - Rear window heater Indicator lamp not working.
B2540 05 - Rear fog lights not working.
B2575 05 - Dipped beam on irrespective of position of light switch.
B2585 05 - Dipped beam on with light switch in position 1.
B3089 0F - Message appears in display.
B3938 04 - Tank hatch lock not working.
B3938 0B - Tank hatch lock not working.
B0473 01 - No heating in car when parking heater activated.
B0473 06 - Faulty cabin fan function when parking heater activated.
B1001 46 - Message appears in display.
B1448 01
B1448 06
B1428 01
B1428 06
B1016 47
B0092 02 - Message appears in display.
B0092 05 - Message appears in display.
B3057 48 - Car does not start.
B0685 01 - Message appears in display.
B1000 33
B1000 36
B1000 37
B2555 0F - Interior lighting on constantly.
B2556 02 - Interior lighting malfunction.
B2556 0F - Interior lighting not working.
B2610 01 - Interior lighting malfunction.
B2610 02 - Interior lighting malfunction.
B2925 0F - Message appears in display.
B2976 02 - Message appears in display.
B2976 05 - Message appears in display.
B2991 02 - Message appears in display.
B2991 05 - Message appears in display.
B2996 02 - Message appears in display.
B2996 05 - Message appears in display.

B3001 02 - Message appears in display.
B3001 05 - Message appears in display.
B3812 04 - Message appears in display.
B3812 0F - Message appears in display.
B3899 48 - Message appears in display. Car does not start.
B3900 48 - Message appears in display. Car does not start.
B3902 71 - Message appears in display. Car does not start.
B3940 05 - No heating in car when parking heater activated.
B3940 02 - No heating in car when parking heater activated.

CDF
B1000 33 - Malfunction in one of the following systems: EHU@Entertainment Head Unit
B1000 34 - Malfunction in one of the following systems: EHU@Entertainment Head Unit
B1000 35 - Malfunction in one of the following systems: EHU@Entertainment Head Unit
B1000 36 - Malfunction in one of the following systems: EHU@Entertainment Head Unit
B1000 57
B1016 00 - Error message is shown on the display.
B1243 61 - Readout mechanism not functioning.
B3057 48 - Car does not start.
B3899 48 - Message appears in display. Car does not start.
B3900 48 - Message appears in display. Car does not start.
B3902 70 - Message appears in display. Car does not start.
U2155 1F - Intermittent radio function.

CDCR
B1000 33 - Malfunction in one of the following systems: EHU@Entertainment Head Unit
B1000 34 - Malfunction in one of the following systems: EHU@Entertainment Head Unit
B1000 35 - Malfunction in one of the following systems: EHU@Entertainment Head Unit
B1000 36 - Malfunction in one of the following systems: EHU@Entertainment Head Unit
B1000 57
B1016 00 - Error message is shown on the display.
B1248 61 - Readout mechanism not functioning.
B3057 48 - Car does not start.
B3899 48 - Message appears in display. Car does not start.
B3900 48 - Message appears in display. Car does not start.
B3902 70 - Message appears in display. Car does not start.
U2155 1F - Intermittent radio function.

CIM
B3700 02 - Intermittent wiper operation interval control does not work.
B3700 04 - Intermittent wiper operation interval control does not work.
B0000 29 - Message appears in display. Steering column lock not working. The ignition timing can be de-activated at any speed at all.
B0000 59 - Message appears in display. Steering column lock not working.
B0997 34 - Message appears in display. Steering column lock not working. Engine does not start.
B0997 35 - Message appears in display. Steering column lock not working. No starter motor cranking.
B0997 38 - Message appears in display. Steering column lock not working. No starter motor cranking.
B0997 37 - Message appears in display. Steering column lock not working. No starter motor cranking.
B1000 34 - Cannot turn key. Engine does not start. Steering column lock not working.
B1000 35 - Message appears in display. Cannot turn key. Engine does not start. Steering column lock not working.
B1000 36 - Message appears in display. Cannot turn key. Steering column lock not working.
B1000 37 - Message appears in display. Cannot turn key. Engine does not start. Steering column lock not working.
B1000 38 - Message appears in display. Engine does not start. Steering column lock not working.
B1000 39
B3057 00 - Message appears in display. Engine may not start.
B3057 0F - Message appears in display. Engine may not start.
B3057 48 - Engine may not start.
B1001 41 - Engine does not start. Message appears in display.
B1001 66 - Message appears in display. Cruise control not working.
B1001 67 - Message appears in display.
B1016 00
B1020 30 - Message appears in display. Steering column lock not working.
B1020 34 - Message appears in display. Steering column lock not working.
B1020 35 - Message appears in display. Steering column lock not working.
B1020 36 - Message appears in display. Steering column lock not working.
B1020 37 - Message appears in display. Steering column lock not working.
B1368 0F - Steering column lock not working.
B1368 00 - Car does not start. Steering column lock not working. Possible that ignition key cannot be turned.
B2810 02 - Steering wheel buttons not working.
B2810 04 - Steering wheel buttons not working.
B2810 0F - Steering wheel buttons not working.
B2955 00 - Engine does not start.
B3109 00 - Remote control indicates weak battery. Message appears in display.
B3110 00 - Remote control indicates weak battery. Message appears in display.
B3111 00 - Remote control indicates weak battery. Message appears in display.

B3112 00 - Remote control indicates weak battery. Message appears in display.
B3113 00 - Remote control indicates weak battery. Message appears in display.
B3114 00 - Lock/unlock with remote control not working
B3115 00 - Lock/unlock with remote control not working
B3116 00 - Lock/unlock with remote control not working
B3117 00 - Lock/unlock with remote control not working
B3118 00 - Lock/unlock with remote control not working
B3598 02 - Cruise control not working.
B3598 04 - Cruise control not working.
B3598 0F - Cruise control not working.
B3700 0F
B3800 02 - Direction indicators not working.
B3806 05 - Main beam flash not working.
B3924 00 - Message appears in display. Engine does not start.
B3925 00 - Message appears in display. The engine may not start.
U1500 01 - Cannot turn key. Message appears in display.
U1500 0F - Engine does not start. Message appears in display. Cannot turn key.
U1501 01 - Message appears in display. Cannot turn key. Steering column lock not working. Engine does not start.
U1501 0F - Message appears in display. Cannot turn key. Steering column lock not working. Engine does not start.
U2100 00
U2100 0F - Intermittent actuation of the following functions: Start Central Locking Instruments Air Condition Control Radio
C0547 01 - Cannot turn key. Message appears in display. Engine does not start.
C0547 04 - Message appears in display. Engine does not start.
C0548 01 - Cannot turn key. Message appears in display. Steering column lock not working.
C0548 08 - Message appears in display. Steering column lock not working. Cannot turn key.
C0549 01 - Message appears in display. Steering column lock not working. Cannot turn key.
C0549 08 - Message appears in display. Steering column lock not working. Cannot turn key.
C0544 00 - ESP warning lamp on.
C0490 01
C0460 00 - ESP warning lamp on.
C0253 00 - ESP warning lamp on.
B1383 00 - Message appears in display.
B3927 00 - Engine does not start.
B3922 00 - Stalk Switch Wiper Front Circuit, Malfunction
B3935 00 - Message appears in display. Ignition cannot be switched off.
B3943 48 - Cannot turn key. Steering column lock not working. Error message is shown on the display.
B3945 00 - Cannot turn key. Message appears in display. Engine does not start.

B3946 00 - Error message is shown on the display. Cannot turn key. Engine does not start.
B3947 00 - Cannot turn key. Error message is shown on the display.
B3948 00 - Message appears in display. Possible that ignition key cannot be turned. The engine may not start.
B3977 00 - Engine does not start.
B3978 00 - Engine does not start. Message appears in display.
B3979 00 - Message appears in display. Engine does not start.
B3981 00 - Message appears in display. Engine may not start.
B3984 00 - Message appears in display.
B3985 00
B3987 00
B2911 00
B2915 00
B2919 00
B3056 00 - Cannot turn key. Engine does not start. Message appears in display.
B3055 00 - Message appears in display. Key cannot be turned in ignition switch. Engine does not start.
B3060 00 - Message appears in display. Engine does not start.
B1440 00 - Error message is shown on the display.
B1440 0F - Error message is shown on the display. Engine does not start. Ignition cannot be switched off or key cannot be removed from ignition switch. Steering column lock not working.
B1440 71 - Error message is shown on the display. Steering column lock not working. Engine does not start.
B3622 05 - Horn not working. No Sentronic function.
B3622 0F - Horn not working. No Sentronic function.
B3622 59 - Horn not working. No Sentronic function.
B1020 31 - Message appears in display. Steering column lock not working.
B1020 32 - Message appears in display. Steering column lock not working.
B1445 01 - Engine does not start. Steering column lock not working.
B1445 02 - Engine does not start. Steering column lock not working.
C0490 06 - Message appears in display. Steering column lock not working. Possible that ignition key cannot be turned.
U1500 38 - None
C0547 02 - Message appears in display. Engine does not start.
C0549 06 - Message appears in display. Steering column lock not working. Cannot turn key.
C0548 06 - Message appears in display. Steering column lock not working. Cannot turn key.
B1440 57 - Steering column lock not working.
B1440 58 - Steering column lock not working. Message appears in display.
B2657 00 - No illumination of steering wheel controls.
B3948 0F - The engine may not start. Possible message on the display

CU GSM
B1000 34 - No function
B1000 35 - No function
B1000 36 - No function
B1000 57 - No function
B1001 41 - No function
B2500 01 - Microphone not functioning.
B2500 02 - Microphone not functioning.
B2500 04 - Microphone not functioning.
B2500 08 - Microphone has poor pick-up efficiency.
U1000 08 - Navigation system out of order.
U1000 72 - Navigation system out of order.
U1501 57 - No Bluetooth function.
B1003 08 - Bluetooth function does not shut down. No Bluetooth function.
U1005 08 - Navigation system out of order.
U1500 08 - No phone function.
B2470 02 - No coverage
B2470 04 - No coverage
B2485 04 - No Bluetooth function.

CU AMPS
B1000 34 - "On Star System Malfunction. Contact Service." shown on the display.
B1000 35 - "On Star System Malfunction. Contact Service." shown on the display.
B1000 36 - "On Star System Malfunction. Contact Service." shown on the display.
B1000 57 - "On Star System Malfunction. Contact Service." shown on the display.
B1001 41 - No function
B1016 00 - No function
B2500 01 - "On Star System Malfunction. Contact Service." shown on the display. Microphone not functioning.
B2500 02 - "On Star System Malfunction. Contact Service." shown on the display. Microphone not functioning.
B2500 04 - "On Star System Malfunction. Contact Service." shown on the display. Microphone not functioning.
B2500 08 - "On Star System Malfunction. Contact Service." shown on the display. Microphone not functioning.
U1000 08 - "On Star System Malfunction. Contact Service." shown on the display.
U1000 72 - "On Star System Malfunction. Contact Service." shown on the display.
U1005 08 - "On Star System Malfunction. Contact Service." shown on the display.
U1500 08 - "On Star System Malfunction. Contact Service." shown on the display. No phone function.
B0047 02 - "On Star System Malfunction. Contact Service." shown on the display.
B0047 04 - "On Star System Malfunction. Contact Service." shown on the display.

B0047 08 - "On Star System Malfunction. Contact Service." shown on the display.
B2476 02 - "On Star System Malfunction. Contact Service." shown on the display. OnStar buttons not working.
B2476 04 - "On Star System Malfunction. Contact Service." shown on the display. OnStar buttons not working.
B2476 08 - "On Star System Malfunction. Contact Service." shown on the display. OnStar buttons not working.

PU
B1000 34 - No function
B1000 35 - No function
B1000 36 - No function
B1000 57 - No function
B1001 41 - No function
U1000 08 - Navigation system out of order.
U1000 72 - Navigation system out of order.
U1005 08 - Navigation system out of order.

DDM
B1721 01 - Power mirror cannot be operated
B1721 02 - Power mirror cannot be operated
B1721 04 - Power mirror cannot be operated
B1000 30 - Diagnostic communication works. Control module outputs switched off. Central locking, window lifts and door mirrors out of order.
B1000 34 - Diagnostic communication works. Control module outputs switched off. Central locking, window lifts and door mirrors out of order.
B1000 35 - Diagnostic communication works. Control module outputs switched off. Central locking, window lifts and door mirrors out of order.
B1000 36 - Incorrect end position (electric window lift).
B1000 37 - Electric window lift cannot be operated.
B1000 40 - Electric window lift cannot be operated.
B1339 00 - Electric window lift cannot be operated.
B1364 04 - No memory function or retraction function for door mirrors. Manual setting works.
B1549 01 - Folding out of door mirrors, out of order.
B1549 02 - Folding out of door mirrors, out of order.
B1583 01 - Memory functions not working Tilt out of order. Manual electric mirror operation working.
B1583 02 - Memory functions not working Tilt out of order. Manual electric mirror operation working.
B1583 04 - Memory functions not working Tilt out of order. Manual electric mirror operation working.
B1585 01 - No memory function or retraction function for door mirrors. Manual setting works.
B1585 06 - No memory function or retraction function for door mirrors. Manual setting works.
B1595 01 - No memory function or retraction function for door mirrors. Manual setting works.
B1595 06 - No memory function or retraction function for door mirrors. Manual setting works.
B1600 01 - Power mirror cannot be operated

B1600 02 - Power mirror cannot be operated
B1640 02 - Mirror heating, out of order.
B1722 01 - Door mirror retraction, out of order.
B1722 02 - Door mirror retraction, out of order.
B1723 01 - The "left/right function" of the electric mirrors does not work.
B1723 02 - The "left/right function" of the electric mirrors does not work.
B1724 01 - Power mirror cannot be operated
B1724 02 - Power mirror cannot be operated
B2635 02 - Courtesy lighting out of order.
B2652 01 - Luggage compartment button and central locking button. Button lighting not working.
B2652 02 - Luggage compartment button and central locking button. Button lighting lit continuously.
B2730 61 - Boot lid/tailgate cannot be opened.
B3130 02 - Central locking, out of order.
B3135 02 - Central locking, out of order.
B3200 61 - Electric window lift release button malfunction.
B3205 01 - Window lift down, out of order.
B3205 02 - Window lift down, out of order.
B3205 04 - Malfunction when lowering window.
B3205 54 - Side window cannot be opened.
B3210 01 - Side window cannot be closed.
B3210 02 - Side window cannot be closed.
B3210 54 - Side window cannot be closed.
B3270 02 - Central locking system cannot be operated with the central locking system button.
B3270 61 - Central locking system cannot be operated with the central locking system button.
B3355 01 - No express function, window up/down.
B3355 02 - No express function, window up/down.
B3375 61 - Driver's door electric window lift cannot be operated.
B3380 61 - Driver's door electric window lift cannot be operated.
B3385 61 - Driver's door electric window lift cannot be operated.
B3390 61 - Driver's door electric window lift cannot be operated.
B3395 61 - Driver's door electric window lift cannot be operated.
B3450 61 - Driver's door electric window lift cannot be operated.
B3455 61 - Driver's door electric window lift cannot be operated.
B3460 61 - Driver's door electric window lift cannot be operated.
B3465 61 - Driver's door electric window lift cannot be operated.
B3470 61 - Driver's door electric window lift cannot be operated.
B3475 61 - Driver's door electric window lift cannot be operated.

B3480 61 - Driver's door electric window lift cannot be operated.
B3542 2B - No express function, window up/down.
B3543 40 - No express function.
B3797 02 - TSL out of order.
B3817 05 - Central locking, out of order.
B3832 45 - Express up not working.
B3932 00 - No express function, window up/down.
B3934 52 - Memory functions not working
B3963 00 - Lock malfunction.
B3992 11 - Express up not working. Pinch protection not working.
B3992 12 - Express up not working. Pinch protection not working.
B3205 01 - Window lift down, out of order.
B3205 02 - Window lift down, out of order.
B3205 04 - Malfunction when lowering window.
B3205 54 - Side window cannot be opened.
B3210 01 - Side window cannot be closed.
B3210 04 - Side window cannot be closed.
B3210 02 - Side window cannot be closed.
B3210 54 - Side window cannot be closed.
B3210 04 - Side window cannot be closed.
B1008 41 - Control module outputs switched off. Central locking, window lifts and door mirrors out of order.
B3057 48 - Car does not start.
B3899 48 - Message appears in display. Car does not start.
B3900 48 - Message appears in display. Car does not start.
B3130 02 - Central locking, out of order.
B3135 02 - Central locking, out of order.
B3797 02 - TSL out of order.
B3817 05 - Central locking, out of order.
B3963 00 - Lock malfunction.
B3933 2B - No express function, window up/down.

DSM
B1000 00 - Seat cannot be operated.
B1000 34 - Seat cannot be operated.
B1000 35 - Seat cannot be operated.
B1000 36 - Comfort mode changed. Seat cannot be operated.
B1000 37 - Seat cannot be operated.

B1008 41 - Memory functions not working
B1725 01 - Memory functions not working Engine does not go in the direction of the button but can go in the opposite direction.
B1725 08 - The button is considered inactive until it is released and activated again. The engine can temporarily go in the opposite direction
B1730 01 - Engine does not go in the direction of the button but can go in the opposite direction. Memory functions not working
B1730 08 - The button is considered inactive until it is released and activated again. The engine can temporarily go in the opposite direction
B1755 01 - Engine does not go in the direction of the button but can go in the opposite direction. Memory functions not working
B1755 08 - The button is considered inactive until it is released and activated again. The engine can temporarily go in the opposite direction
B1760 01 - Engine does not go in the direction of the button but can go in the opposite direction. Memory functions not working
B1760 08 - The button is considered inactive until it is released and activated again. The engine can temporarily go in the opposite direction
B1765 04 - Memory functions not working
B1765 0B - Memory functions not working
B1765 61 - Memory functions not working Output is switched off, tries however to activate the engine once each time the ignition is switched on.
B1770 04 - Memory functions not working The seat cannot be adjusted lengthwise.
B1770 0B - Memory functions not working
B1770 61 - Memory functions not working Engine does not go in the direction of the button but can go in the opposite direction.
B1785 04 - Memory functions not working
B1785 0B - Memory functions not working Output is switched off, tries however to activate the engine once each time the ignition is switched on.
B1785 61 - Memory functions not working Output is switched off, tries however to activate the engine once each time the ignition is switched on.
B1815 01 - Memory functions not working Engine does not go in the direction of the button but can go in the opposite direction.
B1815 08 - The button is considered inactive until it is released and activated again. The engine can temporarily go in the opposite direction
B1820 01 - Memory functions not working Engine does not go in the direction of the button but can go in the opposite direction.
B1820 08 - The button is considered inactive until it is released and activated again. The engine can temporarily go in the opposite direction
B1825 01 - Memory functions not working Seat can jerk during start and stop.
B1825 02 - Memory functions not working Seat can jerk during start and stop.
B1825 04 - Memory functions not working Seat can jerk during start and stop.
B1825 29 - Memory functions not working Seat can jerk during start and stop.
B2365 01 - Memory functions not working Seat can jerk during start and stop.
B2365 02 - No memory functions work Seat can jerk during start and stop.
B2365 04 - Memory functions not working Seat can jerk during start and stop.
B2375 01 - Memory functions not working Seat can jerk during start and stop.
B2375 02 - Memory functions not working Seat can jerk during start and stop.
B2375 04 - Memory functions not working Seat can jerk during start and stop.
B2375 29 - Memory functions not working The control module loses end position calibration for the motor in question.
B2755 01 - Memory button 1, faulty function.
B2755 61 - Memory button 1, faulty function. No memory functions work
B2760 01 - Memory button 2, faulty function.
B2760 61 - Memory button 2, faulty function.

B2765 01 - Memory store button, faulty function.
B2765 61 - Memory store button, faulty function.
B3599 01 - Memory button 3, faulty function.
B3599 61 - Memory button 3, faulty function.
B3907 02 - No seat motors are working.
B3908 01 - Memory functions not working Seat can jerk during start and stop.
B3908 02 - Memory functions not working Seat can jerk during start and stop.
B3908 04 - Memory functions not working Seat can jerk during start and stop.
B3908 29 - Memory functions not working The control module loses end position calibration for the motor in question.
B3917 01 - No memory functions work Engine does not go in the direction of the button but can go in the opposite direction.
B3917 08 - Seat operation button, faulty function.
B3918 01 - No memory functions work Engine does not go in the direction of the button but can go in the opposite direction.
B3918 08 - Seat operation button, faulty function.
B3919 04 - Memory functions not working
B3919 0B - Memory functions not working
B3919 61 - Memory functions not working Output is switched off, tries however to activate the engine once each time the ignition is switched on.
B3920 01 - Memory functions not working No memory functions work
B3920 02 - Memory functions not working
B3920 61 - Memory functions not working Output is switched off, tries however to activate the engine once each time the ignition is switched on.
B3921 01 - Memory functions not working
B3921 02 - Memory functions not working
B3921 61 - Memory functions not working Output is switched off, tries however to activate the engine once each time the ignition is switched on.
B3923 01 - Memory functions not working Seat can jerk during start and stop.
B3923 02 - Memory functions not working Seat can jerk during start and stop.
B3923 04 - Memory functions not working Seat can jerk during start and stop.
B3923 29 - Memory functions not working Seat can jerk during start and stop.
B1001 41 - No memory functions work
U2103 00

CDCF
B1000 33 - Malfunction in one of the following systems: EHU@Entertainment Head Unit
B1000 34 - Malfunction in one of the following systems: EHU@Entertainment Head Unit
B1000 35 - Malfunction in one of the following systems: EHU@Entertainment Head Unit
B1000 36 - Malfunction in one of the following systems: EHU@Entertainment Head Unit
B1000 57
B1016 00 - Error message is shown on the display.
B1248 61 - Readout mechanism not functioning.

B3057 48 - Car does not start.
B3899 48 - Message appears in display. Car does not start.
B3900 48 - Message appears in display. Car does not start.
B3902 70 - Message appears in display. Car does not start.
U2155 1F - Intermittent radio function.

DVD
B1000 34 - Malfunction in one of the following systems: DVD unit.
B1000 35 - Malfunction in one of the following systems: DVD unit.
B1000 36
B1000 57 - Incorrect display texts and illustrations
B1000 63 - Readout mechanism not functioning.
B1000 71 - Malfunction in one of the following systems: DVD unit.
B1001 41 - Control module not configured.
B1016 00 - Control module not configured.
B3057 48 - Control module not configured.
B3899 48 - Control module not configured.
B3900 48 - Message appears in display. Car does not start.
B3902 70 - Message appears in display. Malfunction in one of the following systems: DVD unit.
U2155 1F - Malfunction in one of the following systems: DVD@Digital Versatile Disc

PSG16
P0017 FA - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss. A/C function switched off. Cruise control not working.
P0106 FA - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0112 02 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0113 01 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0116 FA - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Radiator fan runs continuously. Extended glow duration.
P0196 FA - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0117 02 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Radiator fan runs continuously when the engine is running. Extended glow duration.
P0118 01 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Radiator fan runs continuously when the engine is running. Extended glow duration.
P0123 07 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss. Cruise control not working.
P1122 04 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P2135 FA - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine speed cannot be regulated. Idling speed set to 1400 rpm.
P0219 2A - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0243 5A - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss. Cruise control not working. No A/C function.

P0244 5B - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss. Cruise control not working. No A/C function.
P0245 02 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0246 01 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0246 04 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0244 F6 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0314 66 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss. A/C not working, no cooling.
P0314 67 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss. A/C not working, no cooling.
P1380 0B - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0380 0C - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0400 64 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P2413 F8 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss. Cruise control not working.
P0401 5A - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0402 5B - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0403 02 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss. Cruise control not working.
P0404 01 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss. Cruise control not working.
P1403 F6 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss. Cruise control not working.
P1404 04 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss. Cruise control switched off.
P0463 01 - Incorrect display of fuel level
P0341 2C - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss. A/C not working, no cooling.
P0335 FA - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss. A/C not working, no cooling.
P0337 2E - Fault indicator lamp (for further information see WIS Fault diagnosis, general) A/C not working, no cooling.
P0340 2B - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine stops.
P0343 07 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine stops.
P0481 04 - Radiator fan malfunction.
P0481 F6 - Radiator fan malfunction.
P0482 04 - Radiator fan malfunction.
P0483 04 - Radiator fan malfunction.
P0483 F6 - Radiator fan malfunction.
P0532 02 - No cooling.
P0533 01 - No cooling.
P0602 44 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0602 45 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0602 46 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0602 49 - Car does not start.
P0605 F0 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0605 F1 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0605 F2 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.

P0605 F3 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0611 0B - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine stops. The engine may not start.
P0615 04 - Starter motor cannot be started.
P0616 02 - Starter motor malfunction.
P0617 01 - Starter motor malfunction.
P0620 04 - Charging lamp malfunction.
P0620 0F - Charging lamp malfunction. Message appears in display.
P0630 47 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) The car will not start.
P0632 4A - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0642 03 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss. Cruise control not working.
P0643 07 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss. Cruise control not working.
P1647 04 - A/C not working, no cooling.
P0645 F6 - A/C not working, no cooling.
P0646 02 - A/C compressor runs continuously.
P0647 01 - A/C not working, no cooling.
P0650 01 - Check Engine lamp, faulty function with ignition ON.
P0650 02 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0650 04 - CHECK ENGINE lamp does not light when ignition switched ON
P0650 F6 - Check Engine lamp, faulty function with ignition ON.
P0652 03 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Idling speed set to 1400 rpm. Rpm cannot be controlled. Performance loss.
P0653 07 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Idling speed set to 1400 rpm. Rpm cannot be controlled. Performance loss.
P1660 F6 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0660 04 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0661 02 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0662 01 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0670 01 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0670 02 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0670 04 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0670 F6 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0687 FD - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine shut off. Engine does not start.
P0692 01 - Radiator fan malfunction.
P0691 02 - Radiator fan runs continuously.
P0693 02 - Radiator fan runs continuously.
P0694 01 - Radiator fan malfunction.
P0482 F6 - Radiator fan malfunction.

P0695 02 - Radiator fan runs continuously.
P0696 01 - Radiator fan malfunction.
P0698 03 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Idling speed set to 1400 rpm. Rpm cannot be controlled. Cruise control not working.
P0699 07 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Idling speed set to 1400 rpm. Rpm cannot be controlled.
P0704 0F - Cruise control not working.
P0149 5B - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine does not start. Performance loss. A/C not working, no cooling. Cruise control not working.
P1149 5A - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine does not start. Engine shut off. Performance loss. A/C not working, no cooling.
P1168 FB - Performance loss.
P1610 00 - Car does not start. Message appears in display.
P1610 4F - Car does not start. Message appears in display.
P1611 00 - Car does not start. Message appears in display.
P1613 00 - Car does not start. Message appears in display.
P1614 00 - Message appears in display. Car does not start.
P1614 50 - Car does not start. Message appears in display.
P1615 00 - Car does not start. Message appears in display.
P1616 00 - Car does not start. Message appears in display.
P1626 F6 - Engine may not start. Cruise control not working.
P1627 F7
P2100 04 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P2101 F6 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P2102 02 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P2103 01 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0607 01 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0607 02 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0607 08
P0607 2D - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0607 34 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine stops. Engine does not start.
P0607 38
P0607 3A - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine does not start. Engine stops.
P0607 3B
P0607 F1 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0607 F2 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0607 F4 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine does not start. Engine stops.
P0607 F7

P0607 F8 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine stops. Engine does not start.
P0607 03 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0607 07 - Possible loss of performance.
P0607 F0 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) The engine may stall.
P0607 F9 - CHECK ENGINE lamp may be on.
P0607 FA - Fault indicator lamp (for further information see WIS Fault diagnosis, general) The engine may not start. The engine may stall.
P0607 FB - Fault indicator lamp (for further information see WIS Fault diagnosis, general) The motor may turn off.
P0607 FC - Fault indicator lamp (for further information see WIS Fault diagnosis, general) The motor may turn off.
P0607 FD - Fault indicator lamp (for further information see WIS Fault diagnosis, general) The motor may turn off.
P0607 FE - CHECK ENGINE lamp may be on.
P0217 FD - Performance loss.
P0223 07 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Idling speed set to 1400 rpm. Engine speed cannot be regulated. Cruise control not working.
P0197 02 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0198 01 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0298 FC - Performance loss.
P0342 2D - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine stops.
P0503 11 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working.
P0504 FA - Cruise control not working.
P0575 72 - Cruise control malfunction.
P0575 74 - Cruise control malfunction.
P0606 37 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0606 3E - -
P0606 3F - -
P2227 FA - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P2228 03 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P2229 07 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
U0002 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
U0073 FC - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
U0121 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
U0146 00 - Engine does not start.
P0016 FC - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine stops.
P0100 11 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0100 12 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0102 03
P0103 07 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0107 02 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.

P0108 01 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P0336 FD - Fault indicator lamp (for further information see WIS Fault diagnosis, general) A/C not working, no cooling.
P0462 02 - Incorrect display of fuel level
P0500 FA - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Incorrect display of speed and fuel consumption. Cruise control not working.
P0501 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0501 F0 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0686 FD - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine shut off. Engine does not start.
P1627 F8
U0129 71 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P1600 F2

T8
P0106 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working. Limp home The engine speed drops more slowly than usual when the accelerator is released.
P0201 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine misfires or does not start.
P0462 00 - Incorrect display of fuel level
P0463 00 - Incorrect display of fuel level
P0461 00 - D.T.E out or order.
P0498 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0499 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0446 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0452 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0453 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0532 00 - No cooling. No A/C function.
P0533 00 - No cooling. No A/C function.
P0572 00 - Cruise control not working.
P0573 00 - Cruise control not working.
P0724 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working.
P0719 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working.
P0704 00 - Cruise control not working.
P0626 00 - Higher idling speed.
P2228 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P2229 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss. Limp home
P2257 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P2258 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0340 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)

P0451 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0460 00 - Incorrect display of fuel level
P1315 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P1341 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P1342 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P1343 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P1344 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P2300 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Flickering pressure indicator in MIU. Misfiring Jerky movements. Performance loss.
P2301 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Flickering pressure indicator in MIU. Misfiring Jerky movements. Performance loss.
P2303 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Flickering pressure indicator in MIU. Misfiring Jerky movements. Performance loss.
P2304 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Flickering pressure indicator in MIU. Misfiring Jerky movements. Performance loss.
P2306 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Flickering pressure indicator in MIU. Misfiring Jerky movements. Performance loss.
P2307 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Flickering pressure indicator in MIU. Misfiring Jerky movements. Performance loss.
P2309 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Flickering pressure indicator in MIU. Misfiring Jerky movements. Performance loss.
P2310 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Flickering pressure indicator in MIU. Misfiring Jerky movements. Performance loss.
P0115 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Incorrect temperature gauge reading. Radiator fan runs continuously.
P0119 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Incorrect temperature gauge reading.
P0116 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Incorrect temperature gauge reading.
P0107 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working. Limp home Possible misfiring before the DTC is generated. Engine stops when idling.
P0108 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working. Limp home Engine stops when idling.
P0244 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P0202 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine misfires or does not start.
P0203 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine misfires or does not start.
P0204 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine misfires or does not start.
P0033 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P0034 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P0035 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P0101 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working. Limp home Possible driveability problem.

P0102 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working. Limp home
P0103 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working. Limp home
P0117 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Incorrect temperature gauge reading.
P0118 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Incorrect temperature gauge reading.
P0121 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working. Limp home
P0122 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working. Limp home
P0123 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working. Limp home
P0221 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working. Limp home
P0223 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working. Limp home
P0222 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working. Limp home
P0245 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P0246 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P0337 00 - Malfunction Indicator Lamp Engine cannot be started during permanent fault. Engine dies while running/idling. Message in SID regarding TCM and TCS/ESP.
P0339 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Jerky movements. Message in SID regarding TCM and TCS/ESP.
P0544 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0545 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0546 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0551 00 - No load compensation for power steering. Higher idling speed.
P0621 00 - Charging lamp on with engine running. Higher idling speed.
P0625 00 - Higher idling speed.
P0638 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P0685 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine stops. Engine does not start.
P0686 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine does not start. Engine stops.
P0687 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine does not start. Engine shut off.
P0691 00 - Radiator fan malfunction. No A/C function. Torque Reduction
P0692 00 - Radiator fan malfunction. No A/C function. Torque Reduction
P0693 00 - Radiator fan malfunction. No A/C function. Torque Reduction
P0694 00 - Radiator fan malfunction. No A/C function. Torque Reduction
P0695 00 - Radiator fan malfunction. No A/C function. Torque Reduction
P0696 00 - Radiator fan malfunction. No A/C function. Torque Reduction
P1312 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Uneven running and misfiring.
P2121 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home Message appears in display.
P2122 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home Message appears in display.
P2123 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home Message appears in display.
P2126 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home Message appears in display.
P2127 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home Message appears in display.

P2128 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home Message appears in display.
P2135 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working. Limp home
P2138 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Performance loss.
P2227 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P2500 00 - Charging lamp on with engine running. Higher idling speed.
P2501 00 - Higher idling speed.
P0501 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working. Message appears in display. TCS/ESP lamp light in dashboard.
P0441 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0030 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0031 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0032 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0036 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0037 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0038 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0112 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P0113 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P0125 00 - Malfunction Indicator Lamp
P0131 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0132 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0133 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0137 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0138 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0140 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0171 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) The engine may stop after starting, run unevenly and misfire.
P0172 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) The engine may stop after starting, run unevenly and misfire.
P0236 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0237 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P0238 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P0325 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Poor engine torque.
P0300 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) (Check Engine lamp flashes if diagnostics has detected a misfire that is harmful to the catalytic converter). Uneven running and misfiring.
P0301 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) (Check Engine lamp flashes if diagnostics has detected a misfire that is harmful to the catalytic converter). Uneven running and misfiring.
P0302 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) (Check Engine lamp flashes if diagnostics has detected a misfire that is harmful to the catalytic converter). Uneven running and misfiring.
P0303 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) (Check Engine lamp flashes if diagnostics has detected a misfire that is

harmful to the catalytic converter). Uneven running and misfiring.
P0304 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) (Check Engine lamp flashes if diagnostics has detected a misfire that is harmful to the catalytic converter). Uneven running and misfiring.
P0313 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) (Check Engine lamp flashes if diagnostics has detected a misfire that is harmful to the catalytic converter). Uneven running and misfiring.
P0411 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0420 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0442 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Possible smell of petrol.
P0444 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0445 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0455 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Possible smell of petrol.
P0456 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Possible smell of petrol.
P0506 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Higher idling speed.
P0507 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Higher idling speed.
P0600 00 - Engine does not start. Message in SID regarding TCM and TCS/ESP. All values in MIU are frozen. No communication with the engine management system. Cruise control not working.
P0601 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine shut off.
P0602 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0604 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine does not start.
P0606 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P0607 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P0610 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0616 00 - Starter motor cannot be started. The starter motor may function independently.
P0617 00 - Starter motor cannot be started.
P0628 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine does not start.
P0629 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Engine does not start. Fuel pump running without ignition on.
P0630 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0632 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P0633 00 - The car will not start.
P0641 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P0646 00 - A/C not working, no cooling. Compressor may run continuously. Coolant may have been drained from the AC system via the safety valve when the compressor has been in continuous operation.
P0647 00 - A/C not working, no cooling.
P0651 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P1131 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P1132 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P1340 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)

P1442 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P1451 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P1452 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P1453 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P1455 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P1456 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P1492 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P1493 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)
P1523 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working. Limp home
P1606 00
P1609 00 - The car will not start.
P1610 00 - None
P1611 00 - The car will not start.
P1613 00 - The car will not start.
P1614 00 - The car will not start.
P1615 00 - The car will not start.
P1619 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) The car will not start.
P1623 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Message appears in display. Limp home
P1624 00 - Engine may not start.
P1625 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working. Message appears in display.
P1680 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P1681 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Limp home
P1682 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) No starter motor cranking. Engine does not start. Engine shut off.
P2176 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) Cruise control not working. Limp home
P2187 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) The engine may stop after starting, run unevenly and misfire or run at high rpm.
P2188 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general) The engine may stop after starting, run unevenly and misfire.
P2195 00 - Possible engine stop after starting, seizing, misfiring or running at high idle speed.
P2196 00 - Possible engine stop after starting, seizing, misfiring or running at high idle speed.
P2537 00 - None
P2535 00 - None
P1616 00 - The car will not start.
P0134 00 - Fault indicator lamp (for further information see WIS Fault diagnosis, general)

EHU
B1000 33 - Malfunction in one of the following systems: EHU@Entertainment Head Unit
B1000 34 - Malfunction in one of the following systems: EHU@Entertainment Head Unit

B1000 35 - Malfunction in one of the following systems: EHU@Entertainment Head Unit
B1000 36 - Malfunction in one of the following systems: EHU@Entertainment Head Unit
B1000 57
B1001 41 - Error message is shown on the display.
B1016 00 - Error message is shown on the display.
B1026 0E - No sound from the left-hand front loudspeaker.
B1027 02 - No sound in the loudspeakers.
B1028 05 - No sound in the loudspeakers.
B1029 04 - No sound from the left-hand front loudspeaker.
B1036 0E - No sound from the right-hand front loudspeaker.
B1037 02 - No sound in the loudspeakers.
B1038 05 - No sound in the loudspeakers.
B1039 04 - No sound from the right-hand front loudspeaker.
B1046 0E - No sound from the left-hand rear loudspeaker.
B1047 02 - No sound in the loudspeakers.
B1048 05 - No sound in the loudspeakers.
B1049 04 - No sound from the left-hand rear loudspeaker.
B1056 0E - No sound from the right-hand rear loudspeaker.
B1057 02 - No sound in the loudspeakers.
B1058 05 - No sound in the loudspeakers.
B1059 04 - No sound from the right-hand rear loudspeaker.
B1261 02 - Poor/no reception.
B1263 04
B3057 48 - Car does not start.
B3899 48 - Message appears in display. Car does not start.
B3900 48 - Message appears in display. Car does not start.
B3902 70 - Message appears in display. Car does not start.
U2155 1F - Intermittent radio function.

ICM1
B1000 32
B1000 33
B1000 34
B1000 35
B1000 36
B1000 57
B1001 41 - Message appears in display.

B1016 00
B3057 48
B3899 48
B3900 48
B3902 70
B3924 00
B3925 00
B3926 00
B3927 00
B3928 00
B3929 00
B3978 00
B3979 00
B3980 00
B3981 00 - Message appears in display.
B3982 00 - Message appears in display.
B3983 00 - Message appears in display.
B3984 00 - Message appears in display.
B3985 00 - Message appears in display.
B3986 00 - Message appears in display.
B3987 00 - Message appears in display.
B3988 00 - Message appears in display.
B3989 00 - Message appears in display.
U1304 00
B1019 07 - Slow response in cold weather. Display too warm. Poor contrast.
B1019 08
B1019 09 - Faulty display illumination (dark or light).
B1019 0B - Slow response in cold weather. Display too warm. Poor contrast.
B1019 17 - Slow response in cold weather. Display too warm. Poor contrast.
B1019 33
B1019 34 - SID No Message Data
B1019 35 - SID No Message Data
B1019 36 - SID No Message Data
B1019 54 - Faint display text.
B2911 00
B2912 00
B2915 00

B2916 00
B2919 00
B2920 00
U2155 04
U2155 1F
B1000 09
B1000 08

ICM2
B1000 08
B1000 32
B1000 33
B1000 34
B1000 35
B1000 36
B1000 57
B1001 41 - Message appears in display.
B1016 00
B3057 48
B3899 48
B3900 48
B3902 70
B3924 00
B3925 00
B3926 00
B3927 00
B3928 00
B3929 00
B3978 00
B3979 00
B3980 00
B3981 00 - Message appears in display.
B3982 00 - Message appears in display.
B3983 00 - Message appears in display.
B3984 00 - Message appears in display.
B3985 00 - Message appears in display.
B3986 00 - Message appears in display.

B3987 00 - Message appears in display.
B3988 00 - Message appears in display.
B3989 00 - Message appears in display.
U1304 00
B1019 07 - Slow response in cold weather. Display too warm. Poor contrast.
B1019 08
B1019 09 - Faulty display illumination (dark or light).
B1019 0B - Slow response in cold weather. Display too warm. Poor contrast.
B1019 17 - Slow response in cold weather. Display too warm. Poor contrast.
B1019 33
B1019 34 - SID No Message Data
B1019 35 - SID No Message Data
B1019 36 - SID No Message Data
B1019 54 - Faint display text.
B2911 00
B2912 00
B2915 00
B2916 00
B2919 00
B2920 00
U2155 04
U2155 1F
B1000 09

ICM3
B1023 04
B1023 08
B1023 57
B1023 63
B1019 07 - Slow response in cold weather. Display too warm. Poor contrast.
B1019 08
B1019 09 - Faulty display illumination (dark or light).
B1019 0B - Slow response in cold weather. Display too warm. Poor contrast.
B1019 17 - Slow response in cold weather. Display too warm. Poor contrast.
B1019 33
B1019 34 - SID No Message Data
B1019 35 - SID No Message Data

B1019 36 - SID No Message Data
B1019 54 - Faint display text.
B1000 08
B1001 41 - Message appears in display.
B1000 32
B1000 33
B1000 34
B1000 35
B1000 36
B1000 57
B1016 00
B1020 34
B1020 35
B1020 36
B3057 48
B3899 48
B3900 48
B3902 70
B3924 00
B3925 00
B3926 00
B3927 00
B3928 00
B3929 00
B3978 00
B3979 00
B3980 00
B3981 00 - Message appears in display.
B3982 00 - Message appears in display.
B3983 00 - Message appears in display.
B3984 00 - Message appears in display.
B3985 00 - Message appears in display.
B3986 00 - Message appears in display.
B3987 00 - Message appears in display.
B3988 00 - Message appears in display.
B3989 00 - Message appears in display.
U1304 00

B2911 00
B2912 00
B2915 00
B2916 00
B2919 00
B2920 00
U2155 04
U2155 1F
B1000 09
B1020 32
B1020 33

MIU
B1000 32 - Main instrument unit not working or working improperly.
B1000 33 - Main instrument unit not working or working improperly.
B1000 34 - Main instrument unit not working or working improperly.
B1000 35 - Main instrument unit not working or working improperly.
B1000 36 - Main instrument unit not working or working improperly.
B1001 41 - Error message is shown on the display.
B1016 00 - Car does not start.
B2821 0F - Trip odometer cannot be reset.
B2821 61 - Trip odometer cannot be reset.
B3057 48 - Car does not start.
B3899 48 - Car does not start.
B3900 48 - Car does not start.
B3902 70 - Car does not start.

SPA
B0958 01 - Message appears in display. SPA stops all measurements and the acoustic signals from SID for SPA are switched off.
B0958 06 - Message appears in display. SPA stops all measurements and the acoustic signals from SID for SPA are switched off.
B0958 0F - Message appears in display. SPA stops all measurements and the acoustic signals from SID for SPA are switched off.
B0959 01 - Message appears in display. SPA stops all measurements and the acoustic signals from SID for SPA are switched off.
B0959 06 - Message appears in display. SPA stops all measurements and the acoustic signals from SID for SPA are switched off.
B0959 0F - Message appears in display. SPA stops all measurements and the acoustic signals from SID for SPA are switched off.
B0960 01 - Message appears in display. SPA stops all measurements and the acoustic signals from SID for SPA are switched off.
B0960 06 - Message appears in display. SPA stops all measurements and the acoustic signals from SID for SPA are switched off.
B0960 0F - Message appears in display. SPA stops all measurements and the acoustic signals from SID for SPA are switched off.

B0961 01 - Message appears in display. SPA stops all measurements and the acoustic signals from SID for SPA are switched off.
B0961 06 - Message appears in display. SPA stops all measurements and the acoustic signals from SID for SPA are switched off.
B0961 0F - Message appears in display. SPA stops all measurements and the acoustic signals from SID for SPA are switched off.
B1000 08 - Parking assistance not working. Message appears in display.
B1000 2C - Parking assistance not working. Message appears in display.
B1000 34 - Parking assistance not working. Message appears in display.
B1000 35 - Parking assistance not working. Message appears in display.
B1000 36 - Parking assistance not working. Message appears in display.
B1001 42 - Parking assistance not working. Message appears in display.
U2101 46 - Parking assistance not working. Message appears in display.
U2103 00
U2107 00
U2139 00 - Message appears in display.
U2140 00 - Message appears in display.
U2141 00
B1350 01 - Message appears in display. SPA stops all measurements and the acoustic signals from SID for SPA are switched off.
B1350 02 - Message appears in display. SPA stops all measurements and the acoustic signals from SID for SPA are switched off.
U2116 00

PDM
B3542 2B - No express function, window up/down.
B1000 30 - Electric window lift cannot be operated.
B1000 34 - Electric window lift cannot be operated.
B1000 35 - Electric window lift cannot be operated.
B1000 36 - Incorrect end position (electric window lift).
B1000 37 - Electric window lift cannot be operated.
B1000 40 - Electric window lift cannot be operated.
B1008 41 - No express function. Electric window lift jerks during operation.
B1339 00 - Electric window lift cannot be operated.
B1364 04 - No memory function or retraction function for door mirrors. Manual setting works.
B1549 01 - Folding out of door mirrors, out of order.
B1549 02 - Folding out of door mirrors, out of order.
B1583 01 - No memory function or retraction function for door mirrors. Manual setting works.
B1583 02 - No memory function or retraction function for door mirrors. Manual setting works.
B1583 04 - No memory function or retraction function for door mirrors. Manual setting works.
B1585 01 - No memory function or retraction function for door mirrors. Manual setting works.
B1585 06 - No memory function or retraction function for door mirrors. Manual setting works.

B1595 01 - No memory function or retraction function for door mirrors. Manual setting works.
B1595 06 - No memory function or retraction function for door mirrors. Manual setting works.
B1600 01 - Power mirror cannot be operated
B1600 02 - Power mirror cannot be operated
B1640 02 - Mirror heating, out of order.
B1722 01 - Door mirror retraction, out of order.
B1722 02 - Door mirror retraction, out of order.
B1723 01 - Power mirror cannot be operated
B1723 02 - Power mirror cannot be operated
B1724 01 - Power mirror cannot be operated
B1724 02 - Power mirror cannot be operated
B2635 02 - Courtesy lighting function defective
B2652 01 - Button lighting not working.
B2652 02 - Button lighting lit continuously.
B3057 48 - Car does not start.
B3130 02 - Central locking, out of order.
B3135 02 - Central locking, out of order.
B3170 61 - Electric window lift cannot be operated.
B3175 61 - Electric window lift cannot be operated.
B3205 01 - Malfunction when lowering window.
B3205 02 - Malfunction when lowering window.
B3205 04 - Malfunction when lowering window.
B3205 54 - Side window cannot be opened.
B3210 01 - Side window cannot be closed.
B3210 02 - Side window cannot be closed.
B3210 04 - Side window cannot be closed.
B3210 54 - Side window cannot be closed.
B3270 02 - Central locking system cannot be operated with the central locking system button.
B3270 61 - Central locking system cannot be operated with the central locking system button.
B3280 61 - Electric window lift cannot be operated.
B3355 01 - No express function, window up/down.
B3355 02 - No express function, window up/down.
B3543 40 - No express function.
B3797 02 - TSL out of order.
B3817 05 - Central locking, out of order.
B3832 45 - Express up not working.
B3899 48 - Message appears in display. Car does not start.

B3900 48 - Message appears in display. Car does not start.
B3902 70 - Message appears in display. Car does not start.
B3932 00 - No express function, window up/down.
B3933 02 - No express function, window up/down.
B3934 52 - Memory functions not working
B3963 00 - Lock malfunction.
B3992 11 - Express up not working. Pinch protection not working.
B3992 12 - Express up not working. Pinch protection not working.
B3205 01 - Malfunction when lowering window.
B3205 02 - Malfunction when lowering window.
B3205 04 - Malfunction when lowering window.
B3205 54 - Side window cannot be opened.
B3210 01 - Side window cannot be closed.
B3210 02 - Side window cannot be closed.
B3210 04 - Side window cannot be closed.
B3210 54 - Side window cannot be closed.
B3130 02 - Central locking, out of order.
B3135 02 - Central locking, out of order.
B3797 02 - TSL out of order.
B3817 05 - Central locking, out of order.
B3963 00 - Lock malfunction.
B3933 2B - No express function, window up/down.

REC
B3930 01 - Message appears in display.
B3930 02 - Message appears in display.
B3930 04 - Message appears in display.
B3881 02 - LH rear lights, malfunction. Message appears in display.
B3881 04 - LH rear lights, malfunction. Message appears in display.
B3597 01 - Electrical seat operation not working.
B3597 06 - Electrical seat operation always possible or electrical seat operation not working.
B0283 01 - Heated rear window, faulty function.
B0283 06 - Heated rear window, faulty function.
B0525 02 - Right rear direction indicator, faulty function. Message appears in display. Direction indicators are activated at double speed.
B0525 04 - Direction indicators are activated at double speed. Right rear direction indicator, faulty function. Message appears in display.
B0530 02 - Direction indicators are activated at double speed. Left rear direction indicator, faulty function. Message appears in display.
B0530 04 - Direction indicators are activated at double speed. Left rear direction indicator, faulty function. Message appears in display.

B2535 02 - Rear fog light, faulty function. Message appears in display.
B2535 04 - Rear fog light, faulty function. Message appears in display.
B2545 02 - Left-hand reversing light, faulty function. Message appears in display.
B2545 04 - Left-hand reversing light, faulty function. Message appears in display.
B2570 02 - Luggage compartment lighting, faulty function.
B2570 04 - Luggage compartment lighting, faulty function.
B3445 02 - Brake light, faulty function. Message appears in display.
B3445 04 - Brake light, faulty function. Message appears in display.
B3878 02 - Brake light, faulty function. Message appears in display.
B3878 04 - Brake light, faulty function. Message appears in display.
B3880 02 - Right-hand reversing light, faulty function. Message appears in display.
B3880 04 - Right-hand reversing light, faulty function. Message appears in display.
B3882 02 - Right-hand tail lamp, faulty function. Message appears in display.
B3882 04 - Right-hand tail lamp, faulty function. Message appears in display.
B3883 02 - Number plate lighting, faulty function. Message appears in display.
B3883 04 - Number plate lighting, faulty function. Message appears in display.
B3884 02 - Brake light, faulty function. Message appears in display.
B3884 04 - Brake light, faulty function. Message appears in display.
B3931 01 - Message appears in display.
B3931 02 - Message appears in display.
B3931 04 - Message appears in display.
B1000 34
B1000 35
B1000 36
B1020 71 - The windscreen wipers do not work in automatic mode.
B3265 02 - Boot lid/tailgate cannot be opened.
B3265 04 - Boot lid/tailgate cannot be opened.
B1001 44
B1001 46
B1001 47
B3888 04 - Message appears in display.
B3888 04 - Message appears in display.
B3887 04 - Message appears in display.
B3887 04 - Message appears in display.

RLDM
B1000 30 - Electric window lift cannot be operated.

B1000 34 - Electric window lift cannot be operated.
B1000 35 - Electric window lift cannot be operated.
B1000 36 - Incorrect end position (electric window lift).
B1000 37 - Electric window lift cannot be operated.
B1000 40 - Electric window lift cannot be operated.
B1008 41 - Tilt out of order.
B1339 00 - Electric window lift cannot be operated.
B3130 02 - Central locking, out of order.
B3135 02 - Central locking, out of order.
B3180 61 - Driver's door electric window lift cannot be operated.
B3185 61 - Driver's door electric window lift cannot be operated.
B3205 01 - Malfunction when lowering window.
B3205 02 - Malfunction when lowering window.
B3205 04 - Malfunction when lowering window.
B3205 54 - Side window cannot be opened.
B3210 01 - Side window cannot be closed.
B3210 02 - Side window cannot be closed.
B3210 04 - Side window cannot be closed.
B3210 54 - Side window cannot be closed.
B3285 61 - Electric window lift cannot be operated.
B3355 01 - No express function, window up/down.
B3355 02 - No express function, window up/down.
B3542 2B - No express function, window up/down.
B3543 40 - No express function.
B3797 02 - TSL out of order.
B3817 05 - Central locking, out of order.
B3832 45 - Express up not working.
B3932 00 - No express function, window up/down.
B3933 02 - No express function, window up/down.
B3963 00 - Lock malfunction.
B3992 11 - Express up not working. Pinch protection not working.
B3992 12 - Express up not working. Pinch protection not working.
B3205 01 - Malfunction when lowering window.
B3205 02 - Malfunction when lowering window.
B3205 04 - Malfunction when lowering window.
B3205 54 - Side window cannot be opened.
B3210 01 - Side window cannot be closed.

B3210 02 - Side window cannot be closed.
B3210 04 - Side window cannot be closed.
B3210 54 - Side window cannot be closed.
B3933 2B - No express function, window up/down.

RRDM
B1000 30 - Electric window lift cannot be operated.
B1000 34 - Electric window lift cannot be operated.
B1000 35 - Electric window lift cannot be operated.
B1000 36 - Incorrect end position (electric window lift).
B1000 37 - Electric window lift cannot be operated.
B1000 40 - Electric window lift cannot be operated.
B1008 41 - No express function. Electric window lift jerks during operation.
B1339 00 - Electric window lift cannot be operated.
B3130 02 - Central locking, out of order.
B3135 02 - Central locking, out of order.
B3190 61 - Electric window lift cannot be operated.
B3195 61 - Electric window lift cannot be operated.
B3205 01 - Malfunction when lowering window.
B3205 02 - Malfunction when lowering window.
B3205 04 - Malfunction when lowering window.
B3205 54 - Side window cannot be opened.
B3210 01 - Side window cannot be closed.
B3210 02 - Side window cannot be closed.
B3210 04 - Side window cannot be closed.
B3210 54 - Side window cannot be closed.
B3290 61 - Driver's door electric window lift cannot be operated.
B3355 01 - No express function, window up/down.
B3355 02 - No express function, window up/down.
B3542 2B - No express function, window up/down.
B3543 40 - No express function.
B3797 02 - TSL out of order.
B3817 05 - Central locking, out of order.
B3832 45 - Express up not working.
B3932 00 - No express function, window up/down.
B3933 02 - No express function, window up/down.
B3963 00 - Lock malfunction.

B3992 11 - Express up not working. Pinch protection not working.
B3992 12 - Express up not working. Pinch protection not working.
B3205 01 - Malfunction when lowering window.
B3205 02 - Malfunction when lowering window.
B3205 04 - Malfunction when lowering window.
B3205 54 - Side window cannot be opened.
B3210 01 - Side window cannot be closed.
B3210 02 - Side window cannot be closed.
B3210 04 - Side window cannot be closed.
B3210 54 - Side window cannot be closed.
B3933 2B - No express function, window up/down.

SRM
B1000 34 - Sunroof cannot be operated.
B1000 35 - Sunroof cannot be operated.
B1000 36 - Comfort mode changed.
B1000 37 - Sunroof cannot be operated.
B1019 42 - No express function.
B1325 54 - Sunroof cannot be operated.
B1345 04 - Sunroof cannot be operated.
B3660 0C - No express function.
B3661 01 - Sunroof cannot be operated.
B3661 02 - Sunroof cannot be operated.
B3661 0E
B3662 01 - Sunroof cannot be operated.
B3662 02 - Sunroof cannot be operated.
B3663 01 - Sunroof cannot be operated.
B3663 02 - Sunroof cannot be operated.
B3664 01 - Sunroof cannot be operated.
B3664 02 - Sunroof cannot be operated.
B3664 04 - Sunroof cannot be operated.
B3664 0A - Sunroof cannot be operated.
B3664 0E - Sunroof cannot be operated.
B3694 2B - No express function.
B3695 2B - No express function.
B3696 49 - No express function.
B3696 0B - No express function.

TCM
P1743 60 - Message appears in display.
P1743 64 - Message appears in display.
P1805 00 - Message appears in display.
P1807 00 - Message appears in display.
P1808 00 - Message appears in display.
P1804 00 - Message appears in display.
P1816 71
P1820 71
P1835 71
P1895 71
P1896 71
U1803 00 - Message appears in display.
P0218 00 - Message appears in display.
P0560 11 - Message appears in display.
P0560 12 - Message appears in display.
P0602 00 - Message appears in display. Gearbox not shifting gear.
P0605 31 - Message appears in display. TCM in Limp Home.
P0703 71
P0705 08 - Message appears in display. Poor shifting quality.
P0710 02 - Message appears in display.
P0710 04 - Message appears in display.
P0710 0A - Message appears in display.
P0715 00
P0715 08 - Message appears in display.
P0826 06 - Message appears in display. No Sentronic function. Selector lever locked in position P or N.
P0826 01 - Message appears in display. No Sentronic function. Selector lever locked in position P or N.
P0785 01 - Message appears in display.
P0720 00 - Message appears in display.
P0720 08 - Message appears in display.
P0785 04 - Message appears in display.
P0785 06 - Message appears in display.
P0780 60 - Message appears in display.
P0725 71 - Gearbox warning lamp lights in MIU. Message appears in display. Limited shifting function.
P0773 02 - Message appears in display.
P0773 05 - Message appears in display.

P0730 60 - Message appears in display. Poor shifting quality.
P0731 60 - Message appears in display.
P0731 6F - Message appears in display.
P0732 60 - Message appears in display.
P0733 60 - Message appears in display.
P0734 60 - Message appears in display.
P0735 60 - Message appears in display.
P0736 60 - Message appears in display.
P0768 02 - Message appears in display.
P0768 05 - Message appears in display.
P0763 02 - Message appears in display.
P0763 05 - Message appears in display.
P0758 02 - Message appears in display.
P0758 05 - Message appears in display.
P0753 02 - Message appears in display.
P0753 05 - Message appears in display.
P0748 04 - Message appears in display.
P0748 06 - Message appears in display.
P0743 01 - Message appears in display.
P0743 04 - Message appears in display.
P0743 06 - Message appears in display.
P0748 01 - Message appears in display.
U2139 00 - Message appears in display.
P1711 71 - Message appears in display.
P1712 71 - Message appears in display.
P0742 6B - Message appears in display.

TCS
C0035 01 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0035 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0035 06 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0035 26 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0035 29 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0035 2A - ABS warning lamp on Message appears in display. Steering column lock not working.
C0040 01 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0040 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0040 06 - ABS warning lamp on Message appears in display. Steering column lock not working.

C0040 26 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0040 29 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0040 2A - ABS warning lamp on Message appears in display. Steering column lock not working.
C0045 01 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0045 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0050 01 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0050 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0050 06 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0050 26 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0050 29 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0050 2A - ABS warning lamp on Message appears in display. Steering column lock not working.
C0045 06 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0045 26 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0045 29 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0045 2A - ABS warning lamp on Message appears in display. Steering column lock not working.
C0070 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0070 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0070 05 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0065 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0065 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0065 05 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0060 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0060 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0060 05 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0075 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0075 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0075 05 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0080 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0080 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0080 05 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0085 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0085 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0085 05 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0090 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0090 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0090 05 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0095 02 - ABS warning lamp on Message appears in display. Steering column lock not working.

C0095 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0095 05 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0141 02 - Warning lamp lights. Message appears in display.
C0141 04 - TCS warning lamp on. Message appears in display.
C0141 05 - TCS/ESP warning lamp comes on. Message appears in display.
C0146 02 - ABS warning lamp on TCS/ESP warning lamp comes on. Message appears in display.
C0146 04 - TCS/ESP warning lamp comes on. Message appears in display.
C0146 05 - TCS/ESP warning lamp comes on. Message appears in display.
C0151 02 - ABS warning lamp on TCS/ESP warning lamp comes on. Message appears in display. Steering column lock not working.
C0151 04 - TCS/ESP warning lamp comes on. Message appears in display.
C0151 05 - TCS/ESP warning lamp comes on. Message appears in display.
C0156 02 - ABS warning lamp on TCS/ESP warning lamp comes on. Message appears in display. Steering column lock not working.
C0156 04 - TCS/ESP warning lamp comes on. Message appears in display.
C0156 05 - TCS/ESP warning lamp comes on. Message appears in display.
C0121 01 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0121 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0161 00 - TCS/ESP warning lamp comes on. Message appears in display.
C0245 00 - ABS warning lamp on TCS/ESP warning lamp comes on. Message appears in display. Steering column lock not working.
C0550 35 - ABS/TCS/ESP warning lamp on. Message appears in display. Steering column lock not working.
C0550 37 - ABS/TCS/ESP warning lamp on. Message appears in display. Steering column lock not working.
C0550 38 - ABS/TCS/ESP warning lamp on. Message appears in display. Steering column lock not working.
C0551 45 - ABS warning lamp on TCS/ESP warning lamp comes on. Message appears in display. Steering column lock not working.
C0569 00 - TCS/ESP warning lamp comes on. Message appears in display.
C0800 03 - ABS warning lamp on TCS/ESP warning lamp comes on. Message appears in display. Steering column lock not working.
C0800 07 - ABS warning lamp on TCS/ESP warning lamp comes on. Message appears in display. Steering column lock not working.
C0855 03 - Message appears in display. Steering column lock not working.
C0110 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0110 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0252 00 - ABS warning lamp on TCS/ESP warning lamp comes on. Message appears in display. Steering column lock not working.
C0166 59 - ABS/TCS/ESP warning lamp on. Message appears in display. Steering column lock not working.
C0274 59 - ABS/TCS/ESP warning lamp on. Message appears in display. Steering column lock not working.
C0275 59 - ABS/TCS/ESP warning lamp on. Message appears in display. Steering column lock not working.
C0550 00 - ABS/TCS/ESP warning lamp on. Message appears in display. Steering column lock not working.
C0550 34 - ABS/TCS/ESP warning lamp on. Message appears in display. Steering column lock not working.
C0550 36 - ABS/TCS/ESP warning lamp on. Message appears in display. Steering column lock not working.
U2103 00 - TCS/ESP warning lamp comes on. Message appears in display.
U2105 00 - TCS/ESP warning lamp comes on. Message appears in display.

U2105 72 - TCS/ESP warning lamp comes on. Message appears in display.
U2105 7F - TCS/ESP warning lamp comes on. Message appears in display.
U2106 00 - TCS/ESP warning lamp comes on.
U2106 7F - TCS/ESP warning lamp comes on.
U2139 00 - TCS/ESP warning lamp comes on.
U2139 7F
C0131 02 - Warning lamp lights. Message appears in display.
C0131 05 - Warning lamp lights. Message appears in display.
C0131 08 - Warning lamp lights. Message appears in display.

ESP
C0131 02 - Warning lamp lights. Message appears in display.
C0131 05 - Warning lamp lights. Message appears in display.
C0131 08 - Warning lamp lights. Message appears in display.
C0186 00 - ESP warning lamp on. Message appears in display.
C0186 03 - ESP warning lamp on. Message appears in display.
C0186 08 - ESP warning lamp on. Message appears in display.
C0186 11 - ESP warning lamp on. Message appears in display.
C0460 42 - ESP warning lamp on. Message appears in display.
C0460 11 - ESP warning lamp on. Message appears in display.
C0196 00 - ESP warning lamp on. Message appears in display.
C0196 03 - ESP warning lamp on. Message appears in display.
C0196 08 - ESP warning lamp on. Message appears in display.
C0196 11 - ESP warning lamp on. Message appears in display.
C0035 01 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0035 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0035 06 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0035 26 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0035 29 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0035 2A - ABS warning lamp on Message appears in display. Steering column lock not working.
C0040 01 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0040 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0040 06 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0040 26 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0040 29 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0040 2A - ABS warning lamp on Message appears in display. Steering column lock not working.
C0045 01 - ABS warning lamp on Message appears in display. Steering column lock not working.

C0045 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0045 06 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0045 26 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0045 29 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0045 2A - ABS warning lamp on Message appears in display. Steering column lock not working.
C0050 01 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0050 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0050 06 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0050 26 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0050 29 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0050 2A - ABS warning lamp on Message appears in display. Steering column lock not working.
C0060 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0060 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0060 05 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0065 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0065 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0065 05 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0070 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0070 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0070 05 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0075 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0075 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0075 05 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0080 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0080 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0080 05 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0085 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0085 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0085 05 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0090 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0090 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0090 05 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0095 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0095 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0095 05 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0110 02 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0110 04 - ABS warning lamp on Message appears in display. Steering column lock not working.

C0121 01 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0121 04 - ABS warning lamp on Message appears in display. Steering column lock not working.
C0141 02 - Warning lamp lights. Message appears in display.
C0141 04 - TCS warning lamp on. Message appears in display.
C0141 05 - TCS/ESP warning lamp comes on. Message appears in display.
C0146 02 - ABS warning lamp on TCS/ESP warning lamp comes on. Message appears in display.
C0146 04 - TCS/ESP warning lamp comes on. Message appears in display.
C0146 05 - TCS/ESP warning lamp comes on. Message appears in display.
C0151 02 - ABS warning lamp on TCS/ESP warning lamp comes on. Message appears in display. Steering column lock not working.
C0151 04 - TCS/ESP warning lamp comes on. Message appears in display.
C0151 05 - TCS/ESP warning lamp comes on. Message appears in display.
C0156 02 - ABS warning lamp on TCS/ESP warning lamp comes on. Message appears in display. Steering column lock not working.
C0156 04 - TCS/ESP warning lamp comes on. Message appears in display.
C0156 05 - TCS/ESP warning lamp comes on. Message appears in display.
C0161 00 - TCS/ESP warning lamp comes on. Message appears in display.
C0166 59 - ABS/TCS/ESP warning lamp on. Message appears in display. Steering column lock not working.
C0245 00 - ABS warning lamp on TCS/ESP warning lamp comes on. Message appears in display. Steering column lock not working.
C0252 00 - ABS warning lamp on TCS/ESP warning lamp comes on. Message appears in display. Steering column lock not working.
C0274 59 - ABS/TCS/ESP warning lamp on. Message appears in display. Steering column lock not working.
C0275 59 - ABS/TCS/ESP warning lamp on. Message appears in display. Steering column lock not working.
C0550 00 - ABS/TCS/ESP warning lamp on. Message appears in display. Steering column lock not working.
C0550 34 - ABS/TCS/ESP warning lamp on. Message appears in display. Steering column lock not working.
C0550 35 - ABS/TCS/ESP warning lamp on. Message appears in display. Steering column lock not working.
C0550 36 - ABS/TCS/ESP warning lamp on. Message appears in display. Steering column lock not working.
C0550 37 - ABS/TCS/ESP warning lamp on. Message appears in display. Steering column lock not working.
C0550 38 - ABS/TCS/ESP warning lamp on. Message appears in display. Steering column lock not working.
C0551 45 - ABS warning lamp on TCS/ESP warning lamp comes on. Message appears in display. Steering column lock not working.
C0569 00 - TCS/ESP warning lamp comes on. Message appears in display.
C0800 03 - ABS warning lamp on TCS/ESP warning lamp comes on. Message appears in display. Steering column lock not working.
C0800 07 - ABS warning lamp on TCS/ESP warning lamp comes on. Message appears in display. Steering column lock not working.
C0855 03 - Message appears in display. Steering column lock not working.
U2103 00 - TCS warning lamp on. Message appears in display.
U2105 00 - TCS/ESP warning lamp comes on. Message appears in display.
U2105 72 - TCS/ESP warning lamp comes on. Message appears in display.
U2105 7F - TCS/ESP warning lamp comes on. Message appears in display.
U2106 00 - TCS/ESP warning lamp comes on.
U2106 7F - TCS/ESP warning lamp comes on.

U2139 00 - TCS/ESP warning lamp comes on.
U2139 7F
U2143 00 - ESP warning lamp on. Message appears in display.
U2143 7F - ESP warning lamp on. Message appears in display.
U2142 00 - ESP warning lamp on. Message appears in display.
C0895 08 - ESP warning lamp on. Message appears in display.

TPMM
C0550 34 - Message appears in display.
C0550 35 - Message appears in display.
C0550 36 - Message appears in display.
C0551 46 - Message appears in display.
C0750 00 - Message appears in display.
C0750 03 - None
C0755 03 - None
C0755 00 - Message appears in display.
C0760 00 - Message appears in display.
C0760 03 - None
C0765 00 - Message appears in display.
C0765 03 - None
C0780 02 - Message appears in display.
C0780 05 - Message appears in display.
C0781 02 - Message appears in display.
C0781 05 - Message appears in display.
C0782 02 - Message appears in display.
C0782 05 - Message appears in display.
C0783 02 - Message appears in display.
C0783 05 - Message appears in display.
U2103 00 - Message appears in display.

UEC
B2699 02 - Right-hand dipped beam, faulty function. Indication to driver
B2699 04 - Right-hand dipped beam, faulty function. Indication to driver
B2699 0B - Indication to driver Right-hand dipped beam, faulty function.
B0525 04 - Message appears in display. Front right direction indicator, faulty function.
B0530 02 - Front left direction indicator, faulty function. Message appears in display.
B0530 04 - Front left direction indicator, faulty function. Message appears in display.

B2575 02 - Left-hand dipped beam, faulty function. Message appears in display.
B2575 04 - Left-hand dipped beam, faulty function. Message appears in display.
B2575 0B - Left-hand dipped beam, faulty function. Message appears in display.
B0525 02 - Front right direction indicator, faulty function. Message appears in display.
B2580 02 - Left-hand main beam, faulty function. Message appears in display.
B2580 04 - Left-hand main beam, faulty function. Message appears in display.
B2580 0B - Left-hand main beam, faulty function. Message appears in display.
B2698 02 - Right front fog lights, malfunction. Message appears in display.
B2698 04 - Right front fog lights, malfunction. Message appears in display.
B2750 01 - Horn not working.
B2750 06 - Horn not working/horn continually activated.
B3810 01 - Headlamp washer not working.
B3810 06 - Headlamp washer not working/headlamp washer activated continually.
B3866 02 - Message appears in display. Right-hand main beam, faulty function.
B3866 04 - Right-hand main beam, faulty function. Message appears in display.
B3866 0B - Message appears in display. Right-hand main beam, faulty function.
B3867 02 - Front right parking lights, malfunction. Message appears in display.
B3867 04 - Front right parking lights, malfunction. Message appears in display.
B3868 02
B3868 04
B3870 01 - Auxiliary lamp not working.
B3870 06 - Auxiliary lamp not working/lit continually.
B3871 02 - Message appears in display. Front left side marker lights, malfunction.
B3871 04 - Front left side marker lights, malfunction. Message appears in display.
B3872 02 - Front right side marker lights, malfunction. Message appears in display.
B3872 04 - Front right side marker lights, malfunction. Message appears in display.
B3873 01 - Windscreen washing does not work.
B3873 06 - Windscreen washing not working/runs continuously.
B3874 01 - The windscreen wipers do not work at low speed.
B3874 06 - Windscreen wiper(s) not working/operate continually.
B3875 01 - The windscreen wipers do not work.
B3875 06 - Windscreen wiper(s) not working/operate only at high speed.
B3869 02
B3869 04
B2585 02 - Left front parking lights, malfunction. Message appears in display.
B2585 04 - Left front parking lights, malfunction. Message appears in display.
B1000 34

B1000 35
B1000 36
B1001 46
B1001 47
B0010 00 - Reversing lights, malfunction.
B2525 02 - Front fog lights, malfunction. Message appears in display.
B2525 04 - Front fog lights, malfunction. Message appears in display.

SLM
P1801 01 - Selector lever locked in position P or N.
P1801 06 - Selector lever locked in position P or N.
P1802 02 - No Sentronic function. Selector lever locked in position P or N.
P1802 05 - No Sentronic function. Selector lever locked in position P or N.
P1802 08 - Message appears in display. No Sentronic function. Selector lever locked in position P or N.
P0603 36